

# BRP-Powertrain

## Maintenance Manual

T = top  
B = bottom

Fig. 74-19


Engine version 912 ULS/S  
older model

### ◆ NOTE:

Fig. 74-19 shows the wiring diagram for electronic modules with 1-pin, 4-pin and 6-pin plugs.

ignition circuit A: 1 - 2 TOP  
3 - 4 BOTTOM  
ignition circuit B: 1 - 2 BOTTOM  
3 - 4 TOP

bl blue  
br brown  
ge yellow  
gn green  
ro red  
rs pink  
sw black  
ws white  
or orange



d04778

04702